

ORGAN ENTRYWAY MIRROR
EYES FOR THE JOB- EPISODE 206.2
'(PUMP) ORGAN DONOR'



MATERIALS NEEDED

- 1 old pump organ
- 1 36"x48" mirror
- 1 glass cutter to cut mirror
- 1 sanding stone to smooth mirror edges
- 1 tube of clear silicone
- 1 strip of 1 ½" brad nails
- Wood glue
- Wood screws
- 4 coat hooks
- 1 tube of stainable wood filler
- 1 small can of wood stain to match organ wood
- 1 small can of polyurethane for varnishing
- 1 small foam brush for staining

ORGAN ENTRYWAY MIRROR
EYES FOR THE JOB- EPISODE 206.2
'(PUMP) ORGAN DONOR'



STEP BY STEP BUILD PLAN

1. Disassemble the organ
 - a. Remove the bottom half of the back of the organ
 - b. Remove cornices from the front of the organ
 - c. Remove the whole top portion of the lid where the keys used to be
 - d. Remove 3 recessed panels from the back
2. Cut the mirror to fit the recessed panels and install using clear silicone
3. Rip the lid where the keys use to be leaving the decorative edge in tact
4. Make a shelf from the moulding
5. Attach the mirror to the shelf
6. Attach support bracket and coat hook backboard to the mirror
7. Attach 4 coat hooks to the coat hook backboard
8. Fill all screw holes with stainable wood filler
9. Stain all new wood and raw edges to match organ wood